



There is no supervisory circuit for the +1.2V, this is because I can't find a good and available IC. I combine the supervisors on one reset line, and hope this gives enough reliability. Please see the documentation for more info.

OpenARM SBC Power On Design TITLE 2008-08-13		PowerCraft Technology Jelle de Jong <jelledejong@powercraft.nl> GPLv3	
FILE:	../openarm/power-on-reset.sch	REVISION:	v0.1.3j
PAGE:	02 OF 14	DRAWN BY:	OpenARM SBC Project