



There is no supervisory circuit for the +1.2V, this is because I can't find a good and available IC. I combine the supervisors on one reset line, and hope this gives enough reliability. Please see the documentation for more info.

OpenARM SBC Power On Design		PowerCraft Technology	
TITLE 2008-08-13		Jelle de Jong <jelledejong@powercraft.nl>	
FILE: ../openarm/power-on-reset.sch		GPLv3	
PAGE 02	OF 20	REVISION: v0.1.2j	
		DRAWN BY: OpenARM SBC Project	